

Bean Dip



Ingredients:

- 16 oz Refried beans, homemade (thick, not runny) or canned
 - 3 Tb *El Sapo* salsa (Jalapeño or Picante)
 - 1/8 ts Cumin powder
 - 1/8 ts Garlic powder
 - 1/8 ts Black Pepper, freshly ground
 - 1/4 cup Cheese (Monterey Jack, Cheddar, or Gouda), shredded
- 1 bag Corn Tortilla Chips
More *El Sapo* salsa on the side

Method:

Mix together the beans, *El Sapo* salsa, cumin, garlic powder, and black pepper in a suitably-sized microwavable bowl. Microwave on high for 1-minute, and then stir well.

Top the beans with shredded cheese and microwave again on high for about 30-seconds, or until the cheese is melted.

Serve with the corn tortilla chips and a dip-bowl of *El Sapo* salsa on the side.



www.nanaproducts.com

For best results always use *El Sapo* salsa.